

Installation and **MUST READ** Information

Do Not plug the Florida Sportsman Fish Chip into any device besides the GPS unit.

Doing so may corrupt the data stored on the chip, thereby losing your *Florida Sportsman Fish Chip* information. Damaging the chip or corrupting the data is not covered by warranty.

Typical Installation Instructions for Raymarine C120 – Consult your GPS manual to navigate your GPS menu system.



Remove CF Card



Install Fish Chip Card



Push DATA



Push Archive/Transfer



Push Retrieve from card



Push Retrieve Group



You're done!



Replace CF card

- To begin using your *Florida Sportsman Fish Chip* just plug it into the memory card slot in your GPS and TRANSFER the waypoints into the unit's internal memory.** Transferring this data to the GPS may require you to consult your GPS manual to navigate the menu system. **The Fishing spots WILL NOT show up automatically just by plugging in the chip.** (Exceptions are Humminbird units, they usually auto load when you plug in the chip) Since we produce these for 10 different brands and hundreds of models, it's almost impossible to provide detailed instructions on how to load the chip into your particular GPS unit. See our **How-To Video page** on the *Florida Sportsman* website at www.floridasportsman.com/fishchip. If you get stuck, we will try to help you however, we recommend you make a backup of your waypoints onto a separate memory card prior to using the *Florida Sportsman Fish Chip*. This is done in an effort to protect your valuable Fishing spots. **FURUNO OWNERS, use a separate blank chip and backup your current waypoints to do it, prior to using our Fishing Chip.** Please make sure your GPS operating software is up to date. Sometimes, the ability to transfer the fishing spots from the chip to your unit is determined by how up to date your unit's software is. The feature to transfer the data may not be made available due to the GPS software version being out of date (too old).

Additional How-To Instructional Videos for other GPS units are available on the FLORIDA SPORTSMAN website: www.floridasportsman.com/fishchip

GARMIN



LOWRANCE



EAGLE



HUMMINBIRD



- By opening the plastic case containing the product, you automatically agree to the disclaimer and license agreement** provided in this document, and once opened, No refund or returns can be made, only exchanges for same area purchased if there is a problem.
- Please be advised that while we make every effort to provide our GPS fishing data as accurate as possible,** there are subtle differences between one GPS receiver and another. In addition, the sea floor, structures and coastlines are always moving and cannot be guaranteed to be in the exact spot we provide. *Florida Sportsman Fish Chip* provides several hundred (depending on the area purchased) of unique to little known fishing spots that may or may not produce fish at the time you are on the spot. There are many variables, like tide, temperature, moon phase etc that can affect whether or not you will catch fish on the particular spot. If they are not biting on one spot, try another. Wrecks are sometimes difficult to locate, so be persistent.
- The data stored on the *Florida Sportsman Fish Chip* is not replaceable.** If you destroy, delete or damage the chip, Florida Sportsman will not replace the chip or the data. Unfortunately this is in place to discourage piracy. Every single *Florida Sportsman Fish Chip* produced, undergoes a confirming quality control check to make sure the data is on the chip and can be read by the GPS receiver brand.
- No warranty as to the merchantability or fitness of this product can be given.** It is up to the end user to determine its usefulness. The data provided on the *Florida Sportsman Fish Chip* must not be used for navigation purposes. We make no claims as to its accuracy for navigation, routes, obstructions or avoidances. Our liability will not exceed the purchase price of the product.
- The *Florida Sportsman Fish Chip* and the data contained on the chip are copyrighted:** Do Not attempt to make a copy of the data. Do not attempt to share the GPS spots with others. By purchasing the *Florida Sportsman Fish Chip*, you are granted a single instance license to use the data on the chip in one GPS receiver at a time. Duplication, transfer, copying or any other means to reverse engineer the product or data violates international patent and copyright law. We will aggressively pursue prosecution of violators to the fullest extent of the law.
- We recommend that you store your *Florida Sportsman Fish Chip* out of direct sunlight** as the heat may render the chip inoperable. Either plug the chip into the GPS receiver or place it back in the protective plastic case it was shipped in.

Copyright 2012 *Florida Sportsman Fish Chip*

Florida Sportsman Magazine, 2700 Kanner Highway, Stuart, FL 34994 www.floridasportsman.com